




BAITCAST REEL

INTRUDER 100HIL



Key No.	Parts No.	Parts Name.	Key No.	Parts No.	Parts Name.
1	5K166203	PALM SIDE COVER	39	5K133301	SPRING
2	5K136302	CONTROL DIAL	40	5K166401	THUMB BAR
3	6K974701	LEAF SPRING	41	5K166103	GEAR SIDE COVER
4	63535902	SCREW	42	6K176401	O-RING
5	5K136401	GEAR	43	6K454811	THUMB SCREW
6	5K137901	SLIDER CAM-B	44	6K195102	WASHER
7	5K100501	COIL SPRING	45	6K195301	O-RING
8	5K096201	SLIDER CAM-A	46	6K195201	NUT (TENSION KNOB)
9	6K181001	O-RING	47	6K062709	TAP SCREW
10	5K166701	SPOOL COVER	48	6K185401	BEARING
11	5K027001	WASHER	49	63201402	RETAINER
12	6K758901	BEARING	50	6K929901	BEARING PLATE
13	6K468301	RING	51	63535902	SCREW
14	5K102301	MAGNET HOLDER	52	6E096503	WASHER
15	5K047001	TAP SCREW	53	5K084302	GEAR METAL
16	5K137601	SPOOL	54	6K258101	GEAR
17	5K166001	FRAME	55	63737810	WASHER
18	6B339801	RETAINER	56	6K929801	RATCHET
19	6K456801	BUSH	57	6K185204	WASHER
20	6K456403	PIPE	58	6K258304	DRIVE GEAR
21	6K973602	LEVEL WIND	59	6K932401	WASHER
22	6K256504	LEVEL WIND PIN	60	6K9431Z1	WASHER-D
23	6K148802	WASHER	61	6K296802	BUSH
24	6K704403	NUT	62	6K294301	STOPPER ASSEMBLY
25	5K048601	WORM SHAFT	63	6K582201	BALL BEARING
26	6E096503	WASHER	64	6K177302	WASHER
27	6K469301	WORM PINION	66	6K160702	SPRING WASHER
28	6B339801	RETAINER	67	6K193601	WASHER
29	6K395604	TAP SCREW	68	5K1339A5	STAR DRAG
30	6K9304Z1	PILLAR	69	6K161404	LEAF SPRING
31	5K133401	CLUTCH	70	6K811508	HANDLE
33	5K093804	PINION	71	6K178306	NUT
34	6K787601	TAP SCREW	72	5K174001	H/NUT CAP
35	6K261702	BUSH	73	63511805	SCREW
36	5K166501	CLUTCH CAM	74	6K311306	SCREW
37	5K138401	SPRING	75	5K166301	FRONT SUPPORT
38	5K166601	KICK LEVER			