



VT-10SHIL



No.	PART NAME	No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Decoration Plate	24	Overway Clutch	47	Stabilizer Bar	71	Spool Shaft Pin
2	Handle Knob	25	Overway Collar	48	Carrige Screw Pin	72	Ball Bearing
3	Handle Rivet	26	Washer	49	Carrige Screw Gear	73	Spool
4	Crank	27	Drag Washer-A	50	Washer	74	Stopper Spring
5	Ball Bearing	28	Drag Washer-B	51	Guide Bushing-B	75	Ball Bearing
6	Handle Screw	29	Drive Gear	52	Carrige Screw	76	Brake Washer
7	Handle Nut Cap	30	Washer	53	Guide Bushing-A	77	Clutch Lever Screw
8	Handle Nut	31	Ratchet	54	Washer	78	Spool Cover
9	Friction Washer	32	Gear Shaft	55	E-Ring	79	Brake Cam Spring
10	Star Handle Assembly	33	Connecting Gear	56	Holder Guide	80	Magnet Holder Screw
11	Click Holder	34	Stopper	57	Line Guide Holder	81	Magnet Holder
12	Click Spring	35	Ball Bearing	58	Return Pawl	82	Magnet
13	Washer	36	Screw	59	Pawl Cap	83	Magnet Plate
14	Drag Spring Washer	37	Clutch Spring	60	Guide Ring	84	Screw
15	Ball Bearing	38	E-Ring	61	Line Guide Plate	85	Brake Cam Plate
16	Control Cap	39	Pinion Gear	62	Frame	86	Brake Cam
17	Caution Rubber	40	Clutch Bar	63	Front Cover	87	Lock Plate Screw-Short
18	Brake Washer	41	Screw	64	Front Cover Screw-T	88	Lock Plate
19	Ball Bearing	42	Clutch Cam	65	Front Cover Screw-P	89	Push Button Spring
20	O-Ring	43	Click Lever	66	Clutch Lever	90	Left Cover
21	Screw	44	Click Lever Spring	67	Clutch Lever Screw	91	Left Cover Plate
22	Right Cover Screw -Small	45	Washer	68	Clutch Lever Guide Pin	92	Brake Control Lever
23	Right Cover	46	Clutch Link	69	Lock Pin	93	Click Spring
				70	Spool Shaft	94	Lock Plate Screw-Long
						95	Push Button