

Key No.	Parts Name	Key No.	Parts Name	Key No.	Parts Name	Key No.	Parts Name
001	SCREW	032	RETAINER	063	BALL BEARING	094	WASHER
002	H/NUT PLATE	033	TRAVERSE GEAR	064	SPOOL COVER	095	BEARING
003	HANDLE NUT	034	RETAINER	065	SCREW	096	WASHER
004	HANDLE ASSY	035	WASHER	066	BEARING	097	RETAINER
005	WASHER	036	BUSH	067	WASHER	098	O-RING
006	STAR DRAG	037	PIPE	068	GEAR SHAFT ASSY	099	CLAW SPRING
007	CLICK HOLDER ASSY	038	WORM SHAFT	069	SUN GEAR ASSY	100	ANT CLAW
008	BUSH	039	LEVEL WIND ASSY	070	INTERNAL GEAR	101	SCREW
009	TENSION KNOB	040	LEVEL WIND PIN	071	SPOOL ASSY	102	PINION
010	WASHER	041	NUT CAP	072	BALL BEARING	103	COIL SPRING
011	WASHER	042	WASHER	073	SCREW	104	CLUTCH BAR
012	LEAF SPRING	043	SCREW	074	MOTOR BOX	105	CLUTCH CAM
013	LEVER CAP	044	SHAFT-A	075	PACKING-C	106	JOINT GEAR
014	NUT	045	GUARD PLATE	076	MOTOR ASSY	107	WASHER
015	TOOTH WASHER	046	SCREW	077	PACKING-B	108	SCREW
016	SPEED LEVER	047	FRONT COVER-A	078	O-RING-D	109	MAGNET ASSY
017	O-RING-C	048	CONTROL BOX ASSY	079	ONE WAY HOLDER ASSY	110	FRAME COVER ASSY
018	SPRING WASHER	049	SCREW	080	SCREW	111	RETAINER
019	WASHER	050	TAP SCREW	081	WASHER		
020	NUT	051	TAP SCREW	082	DRAG COLLAR		
021	CLUTCH LEVER	052	TAP SCREW	083	WASHER		
022	CAM SPRING	053	LEFT SIDE PLATE	084	DRAG SPRING		
023	CLUTCH LEVER CAM ASSY	054	TUBE	085	WASHER-D3		
024	TOOTH WASHER	055	NUT	086	WASHER		
025	SCREW	056	SPRING WASHER	087	WASHER-A		
026	SCREW	057	CONNECTOR ASSY	088	WASHER-D2		
027	LINE STOPPER	058	WATER CAP	089	DRIVE GEAR		
028	SCREW	059	CODE ASSY	090	WASHER-D1		
029	SCREW	060	FRAME ASSY	091	WASHER-D		
030	SCREW	061	RETAINER	092	RATCHET ASSY		
031	FRONT COVER	062	WASHER	093	GEAR METAL		