


VENTURA

VT-4000 Hi



THE ORDER OF THE PART NUMBER IS BASED ON THAT OF THE REEL ASSEMBLY

NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME
1	FRAME	17	PILLAR(+2)	33	E-RING	49	BUSHING	65	SPOOL ASSEMBLY
2	CLUTCH BAR	18	FRONT COVER	34	CRANK SHAFT SPACER(OPTIONAL)	50	BEARING RETAINER	66	BALL BEARING
3	CLUTCH LINK	19	FRONT COVER SCREW	35	BEARING PLATE SCREW	51	CAST CONTROL CAP	67	BRAKE COLLAR(WHITE)(+6)
4	CLUTCH BAR SCREW	20	HOOD	36	PINION YOKE	52	TENSION WASHER	68	LEVER PLATE
5	LINE GUIDE PIPE	21	HOOD SCREW	37	PINION GEAR	53	SPOOL SPACER (B)	69	LEVER PLATE SPRING(+4)
6	WORM SHAFT	22	CLUTCH SPRING	38	PINION YOKE SPRING(+2)	54	RIGHT SIDE COVER SCREW (A)	70	LOCK LEVER
7	IDLER(S) WASHER(OPTIONAL)	23	CLUTCH CAM	39	RATCHET	55	R/SIDE COVER SCREW (B)(+3)	71	LOCK LEVER SCREW(+2)
8	IDLER(S)	24	RETURN PAWL	40	RATCHET WASHER	56	CLICK PLATE	72	LEFT SIDE COVER ASSEMBLY
9	WORM SHAFT PIN	25	CLUTCH CAM SCREW	41	DRIVE GEAR	57	CLICK LEAF SPRING	73	LOCK PIN
10	LINE GUIDE ASSEMBLY	26	RETURN PAWL SPRING	42	DRAG WASHER (B)	58	DRAG SPRING WASHER(+2)	74	LOCK PIN SPRING
11	WORM SHAFT BUSHING (B)	27	BALL BEARING	43	DRAG WASHER (D)	59	STAR DRAG ASSEMBLY	75	SPOOL COVER ASSEMBLY
12	WORM SHAFT WASHER(OPTIONAL)	28	CRANK SHAFT	44	SLEEVE WASHER(OPTIONAL)	60	LEAF SPRING	76	SPOOL COVER SCREW(+2)
13	E-RING	29	IDLER(L)	45	SLEEVE	61	HANDLE ASSEMBLY	77	SPOOL SPACER(A)
14	LINE GUIDE PAWL	30	IDLER(L) WASHER(A)(OPTIONAL)	46	RIGHT SIDE COVER	62	HANDLE NUT	78	BALL BEARING
15	SPACER(OPTIONAL)	31	BEARING PLATE	47	ONE WAY CLUTCH	63	HANDLE NUT CAP	79	BEARING RETAINER
16	PAWL CAP	32	IDLER(L) WASHER (B)	48	O-RING	64	HANDLE NUT CAP SCREW		