URANO

NU-6500 HiL



MARINE SPORTS

THE ORDER OF THE PART NUMBER IS BASED ON THAT OF THE REEL ASSEMBLY

NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME
1	FRAME	16	E-RING	31	CLUTCH SPRING HOLDER	46	RATCHET WASHER	61	RIGHT SIDE COVER SCREW (B)	76	HANDLE NUT CAP SCREW	91	BEARING RETAINER
2	CLUTCH BAR PLATE	17	PILLAR	32	CAM PLATE SCREW(B)	47	DRIVE GEAR	62	RIGHT SIDE COVER SCREW (C)	77	SPOOL ASSEMBLY	92	
3	CLUTCH BAR ASSEMBLY	18	LINE GUIDE PAWL	33	BALL BEARING	48	DRAG WASHER (B)	63	CLICK PLATE	78	BALL BEARING	93	
4	CLUTCH LINK	19	SPACER(OPTIONAL)	34	CRANK SHAFT	49	DRAG WASHER (D)	64	CLICK LEAF SPRING	79	BRAKE COLLAR(WHITE) (*6)	94	
5	CLUTCH BAR SCREW	20	PAWL CAP	35	IDLER(L)	50	SLEEVE WASHER(OPTIONAL)	65	DRAG SPRING WASHER(*2)	80	LEVER PLATE	95	
6	CLUTCH BAR SUPPORT	21	FRONT COVER	36	IDLER(L) WASHER(A) (OPTIONAL)	51	SLEEVE	66	STAR DRAG	81	LEVER PLATE SPRING(*4)	96	
7	LINE GUIDE ASSEMBLY	22	FRONT COVER SCREW (*2)	37	BEARING PLATE	52	RIGHT SIDE COVER ASSEMBLY	67	LEAF SPRING	82	LOCK LEVER	97	
8	WORM SHAFT	23	YOKE HOLDER	38	IDLER(L) WASHER (B)	53	ONE WAY CLUTCH	68	HANDLE ASSEMBLY	83	LOCK LEVER SCREW(*2)	98	
9	WORM SHAFT BUSHING (A)	24	CLUTCH SPRING BUSHING	39	E-RING	54	O-RING	69	BALL BEARING(*2)	84	LEFT SIDE COVER	99	
10	IDLER(S) WASHER(OPTIONAL)	25	CLUTCH SPRING	40	CRANK SHAFT SPACER(OPTIONAL)	55	BUSHING	70	HANDLE KNOB(*2)	85	LOCK PIN	100	
11	IDLER(S)	26	RETURN PAWL	41	BEARING PLATE SCREW	56	BEARING RETAINER	71	BUSH(*2)	86	LOCK PIN SPRING	101	
12	WORM SHAFT PIN	27	RETURN PAWL SPRING	42	PINION YOKE	57	CAST CONTROL CAP	72	SCREW(*2)	87	SPOOL COVER ASSEMBLY	102	
13	LINE GUIDE PIPE	28	CLUTCH CAM	43	PINION GEAR	58	TENSION WASHER	73	HANDLE KNOB CAP(*2)	88	SPOOL COVER SCREW(*2)	103	
14	WORM SHAFT BUSHING (B)	29	CAM PLATE	44	PINON YOKE SPRING(*2)	59	SPOOL SPACER (B)	74	HANDLE NUT	89	SPOOL SPACER(A)	104	
15	WORM SHAFT WASHER(OPTIONAL)	30	CAM PLATE SCREW(A) (*2)	45	RATCHET	60	RIGHT SIDE COVER SCREW (A)	75	HANDLE NUT CAP	90	BALL BEARING	105	